

Troubleshooting

Problem	Solution
The fan will not start	<ul style="list-style-type: none"> □ Check the main and branch circuit fuses or breakers. □ Check the line wire connections to the fan and switch wire connections in the switch housing. □ Check the battery in the remote control. □ Ensure you are in the normal range of 10-20 feet. □ Remember to turn off the power supply before checking the dip switch settings.
The fan is noisy	<ul style="list-style-type: none"> □ Ensure all motor housing screws are snug. □ Ensure the screws that attach the fan blade bracket to the motor hub are tight. □ Ensure the wire nut connections are not rattling against each other or the interior wall of the switch housing. □ Allow a 24-hour “breaking in” period. Most noises associated with a new fan disappear during this time. □ If you are using the Ceiling Fan light kit, ensure the screws securing the glassware are tight. Check that the light bulbs are also secure. □ Ensure the canopy is a short distance from the ceiling. It should not touch the ceiling. □ Ensure your outlet box is secure and rubber isolator pads were used between the mounting plate and outlet box.
The fan wobbles	<ul style="list-style-type: none"> □ Check that all blade and blade arm screws are secure. □ Most fan wobble problems are caused when blade levels are unequal. Check this level by selecting a point on the ceiling above the tip of one of the blades. Measure from a point on the center of the blade to the point on the ceiling. Rotate the fan until the next blade is positioned for measurement, and measure from the same point on each blade to the ceiling. Repeat for each blade. Any measurement deviation should be within 1/8 in. Run the fan for ten minutes. If the fan continues to wobble please contact Home Decorators Collection Customer Service and a balancing kit will be sent to you at no charge. □ The mounting bracket is not firmly attached to the outlet box. Make sure the mounting bracket is completely tightened to the outlet box. □ The ball of the downrod assembly is not properly seated in the mounting bracket. The ball has a notch that aligns with a tab on the mounting bracket.
The fan turns itself on/off.	<ul style="list-style-type: none"> □ Change the dip switch pattern in the remote control and repeat the learning process found in your ceiling fan owners manual. □ If after you have changed the dip switches to all 16 possible settings, the fan continues to turn itself on/off, replace the remote receiver.
The fan will not change direction.	<ul style="list-style-type: none"> □ The fan needs to be running prior to pushing the reverse button. Press a speed button on your remote and allow the fan to start moving, then press and hold the reverse button for 10 seconds.
The lights are flickering.	<ul style="list-style-type: none"> □ If you are using CFL light bulbs, open the back of the remote control and verify that the “ON/DIM” dipswitch is set to the “ON” position. If you wish to use the “DIM” feature, change the light bulbs to 60-watt max. incandescent bulbs. □ Replace the CFL bulbs with new CFL bulbs. □ Do not use LED bulbs as they may damage the receiver, use CFL or incandescent bulbs only.